


**Model CDSN
Carbon Dioxide Transmitter**

QUICK START GUIDE

1. **Remove** front cover from backplate by squeezing the top and bottom of the backplate.
2. **Mount** the backplate to an electrical box or on a vertical surface away from external influences.
3. **Attach** wires according to the diagram on reverse side.
4. **Scan** QR code with a smart device to open the product web page for additional resources.



WIRING INFORMATION



Included passive sensor:

Sensor A - 10K Ω type 3 NTC thermistor

Sensor B - 10K Ω type 2 NTC thermistor

Sensor F - 20K Ω NTC thermistor

Printed in U.S.A. 12/21
FR# 444647-50 Rev. 1

©Copyright 2021 Dwyer Instruments, Inc.