

Magnehelic® Differential Pressure Gage

QUICK START GUIDE

- 1. Mount** with the gage positioned vertically and free from vibration.


DIFFERENTIAL PRESSURE:

- 1. Connect** the tubing from the high pressure source to either pressure port marked with a “+” symbol.
- 2. Connect** tubing from the low pressure source to either pressure port marked with a “-” symbol. Plug unused ports. See the manual for more configurations.


TO ZERO AFTER INSTALLATION:

Vent one “+” and one “-” port. Use the “zero set” screw to set the pointer on zero.

SURFACE MOUNTING: Locate mounting holes, 120° apart on a 4-1/8" dia. circle. Use No. 6-32 machine screws of appropriate length.



FLUSH MOUNTING: Provide a 4-9/16" dia. opening in panel. Provide a 4-3/4" dia. opening for MP and HP models.



For more information, refer to the user's manual.



Full Manual

Printed in U.S.A. 10/23
FR# 440212-06 Rev.2

©Copyright 2023 Dwyer Instruments, LLC